

If your water is shut off automatically by the Intelli-Sensor system, follow these steps to reset the system and restore the water flow.

Reset instructions for the INTELLI-SENSOR

- **Locate the sensor in your home, this can be done by listening for a beeping or by going to the black receiver box in your utility closet. On the box will be a 5-digit number, taped to your utility closet door will be a list of the sensors, look for that 5-digit number for the location.**
- **Pick it up and dry it until it stops beeping. Temporarily put it somewhere dry.**
- **Return to the shut-off room and push and hold the red button on the black receiver box (picture on the next page) for about three seconds until the flashing red light dims. This will reset the receiver unit and stop it beeping.**
- **Contact a plumber. DO NOT TURN YOUR WATER ON UNTIL THE LEAK IS FIXED OR ISOLATED.**

Instructions to restore the water supply

- **Do not restore the water supply until the plumbing repair has been completed or the fault has been isolated by closing a local appliance valve.**
- **Press and hold the toggle switch, on the black receiver box, to the open position until the valve motor, located by the water heater and is red in color, stops running.**
- **Release the switch.**
- **If the red valve is reading open, this means your water is back on**

Noah Technologies, Inc.

MR-4

OPEN

CLOSE

VALVE

PUSH & HOLD TO RESET

ALARM

BATTERY

LOW BATTERY

Intelli-Sensor
SYSTEM ARMED

MASTER SHOWER		A/C UNIT
MASTER BATH		WATER HEATER
MASTER TOILET		
MASTER SINK 1		
MASTER SINK 2		
MAIN BATH		
MAIN TOILET		
MAIN SINK		
POWDER TOILET		
POWDER SINK		
KITCHEN SINK		
KITCHEN FRIDG		
DISHWASHER		
WASH MACHINE		
UTILITY SINK		

24230 Whip-O-Will Ln. • Bonita Springs, FL 34135
www.Intelli-Sensor.com